




IVR-1XXX






IVR-102



STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **14.0V~15.1V**■

Connect IVR




IVR-103



STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **14.0V~15.1V**■

Connect IVR




IVR-104



STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **14.0V~15.1V**■

Connect IVR

IVR-105



STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **14.0V~15.1V**■

Connect IVR

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

24V

12V

DF(F) White
D+(L) Blue
D-(E) Black

STEP1 : Charge Lamp
STEP2 : Choke Drive
Regulated voltage **14.0V~15.1V**■

Connect IVR

IVR-106

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

24V

12V

S(S/C) Yellow
L(L) Blue
E(E) Black
※Bottom
B(B) Red
F(F) White
C

STEP1 : Skip No Check
STEP2 : Choke Drive
Regulated voltage **14.0V~15.1V**■

Connect IVR

IVR-107

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

24V

12V

L(L) Blue
IG(IG) Purple
S(S/C) Yellow
E(E) Black
Ps(N/P) Orange
F(F) White
※Bottom
B(B) Red
FR

STEP1 : Charge Lamp
STEP2 : Choke Drive
Regulated voltage **14.0V~15.1V**■

Connect IVR

IVR-108

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

24V

12V

L(L) Blue
IG(IG) Purple
S(S/C) Yellow
E(E) Black
Ps(N/P) Orange
F(F for SC) White/Green
※Top
B(B) Red
W
FR

STEP1 : Skip No Check
STEP2 : Choke Drive
Regulated voltage **28.0V~29.1V**■
Only "CN-101" can inspect IVR-109
Connect "Cable Assy2" between B and E terminal.

Connect IVR

IVR-109