




IVR-3XXX






IVR-301



STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **14.0V~15.1V**■

Connect IVR




IVR-302



STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **28.0V~29.1V**■

Connect IVR



IVR-303



STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **14.0V~15.1V**■

Connect IVR

IVR-304



STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage■

Connect IVR