Parallel Gripper HP03E Series



◆Long life

Long life because the cross roller bearing is used for the lever sliding part.

◆High grip accuracy

The repeat accuracy is ± 0.01 mm or less thanks to the mechanism improvement.

◆Dust-proof cover is optional → Addable later on

NBR rubber, fluorine-containing rubber and silicon rubber are available for the cover material. Dust-proof cover set solely sold.

◆Mounting adapter is optional


More variation of gripper mounting adapter types. Further expansion of mounting variation.

Expansion of switch type variations Two lead wire directions: Straight type and L shaped type.

◆Mounting available from 3 directions


You can select the mounting direction freely because three faces have a mounting screw.

Model Code No.



● Dust-proof Cover Set Model Code No. JN - 03 16 Size Material JN: With NBR Rubber Cover JS: With Silicon Rubber Cover JF: With Fluorine Rubber Cover JF: With Fluorine Rubber Cover

■Internal Structure Diagram



Parts List

NO	Name	Material		
1	Main Body	Aluminum Alloy		
2	Head Cover	Aluminum Alloy		
3	Piston Rod	Stainless Steel		
4	Piston	Aluminum Alloy		
5	Magnet	Resin		
6	Pressure Cover	Carbon Steel		
7	Pressure Cover	Aluminum Alloy		
8	Lever	Carbon Tool Steel		
9	Action Lever	Carbon Steel		
10	Rail	Carbon Tool Steel		
11	Fulcrum Pin	Carbon Tool Steel		
12	Press Fit Pin	Carbon Steel		
13	Roller	High Carbon-chromium Bearing Steel		
14	Roller	High Carbon-chromium Bearing Steel		
15	Hole Locating Snap Ring	Hard Steel		
16	O Ring	NBR		
17	Rod Packing	NBR		
18	Piston Packing	NBR		
19	Dust-proof Cover			
20	Cross-recessed Head Screw	Carbon Steel		
21	Pressure Cover	Stainless Steel		

■ Specifications

Fluid		Air
Maximum Operating Pressure	[MPa]	0.7
Proof Pressure	[MPa]	1.05
Operating Temperature	[°C]	0~60 (No Freezing)
Lubrication		Not Required (Required for sliding parts of the machine)
Pipe Bore		M3×0.5(HP03E-6, HP03E-10) M5×0.8(HP03E-16, HP03E-20, HP03E-25)
Maximum Operating Cycle	[Cycle/min]	180
Centering Accuracy	[mm]	±0.15
Repeat Accuracy	[mm]	±0.01
Applicable Switch		ZE, ES Type (Solid State Switch)


Action	Model	Bore Size	Minimum Operating Pressure	Opening/ Closing Stroke	Grippin	g Force N]	Outside Dimensions (T x W x L)	Product Mass	Dust-proof cover mass (additional mass: g)		
Туре		[mm]	[MPa]	[mm]	Close	Open	[mm]	[g]			
	HP03E-6C	6	0.22	4	4.5	5.8	12×19×38	28	28 Not cover mour		unting
	HP03E-10C	10	0.18	4	9.4	14.6	16×23×43	48	JN=6	JS=6	JF=7
Double Acting	HP03E-16C	16	0.12	8	25.5	34	22×34×52	120	JN=8	JS=8	JF=10
	HP03E-20C	20	0.1	12	45.7	60.9	26×45×60.5	218	JN=12	JS=12	JF=16
	HP03E-25C	25	0.1	14	67	87	32×52×68	366	JN=15	JS=15	JF=20
	НРОЗЕ-6А	6	0.4	4	4.1	2.7	12×19×38	28	Not co	ver mou	unting
Single	HP03E-10A	10	0.35	4	4.9	2	16×23×43	49	JN=6	JS=6	JF=8
Acting Normally Open	HP03E-16A	16	0.25	8	21	3.9	22×34×52	121	JN=8	JS=8	JF=10
	HP03E-20A	20	0.25	12	36.4	6.9	26×45×60.5	220	JN=12	JS=12	JF=16
	HP03E-25A	25	0.25	14	54	13.7	32×52×68	368	JN=15	JS=15	JF=20


Note) The grip force is measured at the intermediate position of the opening/closing stroke. It is an effective value when the grip point L is 30 mm and the pressure is 0.5 MPa.


The opening force of the single acting type indicates the spring force.


■Effective Gripping Force (Closing Force)


Double Acting Type
















Single Acting Type
















■ Gripping Point Limit Range













Workpiece Weight Guide

- When workpieces are chucked, the workpiece weight shall be about 1/10 to 1/20 of the grip force specified on the left (Effective Grip Force Table).
- When workpieces are transferred after they are chucked, workpieces may jump out or fall.
 Therefore, the workpiece weight that can be gripped will be lower. (1/30 to 1/50 as a guide)
- The workpiece weight largely differs depending on the workpiece, attachment material, shape, surface condition, workpiece travel speed, travel distance (direct advance, rotation, swing, etc.), etc.




■ Main Body Mounting Method

1 When the through-hole of the main body is used



2 When the mounting screws on the both side of the main body are used





(Excluding ϕ 6)

3 When the screw on the side of the main body is used


4 When the screw on the bottom face of the main body is used

When the switch is mounted, a relief is required because the switch protrudes.







5 When a gripper adaptor (HAE, HFE) is used for mounting (Excluding ϕ 6)



■ Outline Dimensional Drawing of Gripper Adaptor


HAE Type






Type Code	А	В	С	D	Е	F	G	Н	1	J	K	L	Ancillary Bolt (x2)	Product Mass[g] (Including Bolts)
HAE-10	15	15	3	1.3	10	11	11	23	17	10	16	3.4	M3×0.5×8 ^L	11
HAE-16	15	15	3	1.3	10	16	17	34	26	14	22	4.5	M4×0.7×10 ^L	20
HAE-20	15	15	3	1.3	10	18	21	45	35	16	26	5.5	M5×0.8×10 ^L	28
HAE-25	20	17	5	1.3	14	26	26	52	40	20	32	6.6	M6×1×15 ^L	63

HFE Type






Code	۸	Е	G	Н	1		KL		Ancillary	Bolt (x3)	Product Mass[g]	
Type	Α	_	G	П	'	J		_	Gripper Mounting (x2)	Adapter Fixing (x1)	(Including Bolts)	
HFE-10	15	6	11	23	17	10	16	3.4	M3×0.5×16 ^L	M3×0.5×12 ^L	14	
HFE-16	18	8	17	34	26	14	22	4.5	M4×0.7×20 ^L	M4×0.7×16 ^L	35	
HFE-16L	18	10	17	34	26	14	22	4.5	M4×0.7×20 ^L	M4×0.7×16 ^L	33	
HFE-20	19	13	21	45	35	16	26	5.5	M5×0.8×20 ^L	M5×0.8×20 ^L	55	
HFE-25	22	13	26	52	40	20	32	6.6	M6×1×25 ^L	M6×1×25 ^L	96	

■Switch Mounting

Insert the switch into the switch mounting groove. After setting the mounting position, tighten the switch fixing screw with a precision screwdriver. The tightening torque shall be $0.1~\rm N\cdot m$ or less.

Switch Protrusion Distance

No switch protrusion distance is set for the HPO3E series.




Switch Mounting Position Adjustment Method


For external gripping




①Check the workpiece external gripping and full close.



②Insert the switch into the switch mounting groove of the main body in the arrow direction.




3The LED lamp lights up by turning on the switch in the arrow direction.



Tix the switch by a switch fixing screw at the position where the switch is moved 0.6 mm in the arrow direction from the position where the lamp lights up in [3].


For internal gripping




①Check the workpiece internal gripping and full opening.



②Insert the switch into the switch mounting groove of the main body in the arrow direction.




The LED lamp lights up by moving the switch in the arrow direction. It goes off by moving it further.



(a) Fix the switch at the position that is 0.6 mm moved from the position where the LED lamp lights up when it is returned in the arrow direction (reverse direction) in [3].

①Indicates the position where you need to check if the switch is ON. Mount the switch by adjusting it in the order from ① to ④.


Lever Operation and Switch Characteristics





- Opening/Closing Stroke Difference (Opening/Closing Angle Difference)
 The distance from the position where the one side lever moves and the
 switch turns on from the position where the lever moves in the reverse
 direction and the switch turns off is called 'response difference'.
- Switch repeat operation position accuracy
 Variation of the switch ON/OFF position when the one side lever is moved in a certain direction.

Model	Opening/Closing Stroke Difference[mm]	Operation Position Accuracy[mm]
HP03E-6	0.3	0.2
HP03E-10	0.3	0.2
HP03E-16	0.3	0.2
HP03E-20	0.3	0.2
HP03E-25	0.3	0.2

■ Dimensions HP03E-6□










^{*1)} For the single acting type, the opening port cannot be used because it is used for the exhaust plug.

■ Dimensions HP03E-10□











CAD data provided


■Dimensions HP03E-10□※J□







^{*1)} For the single acting type, the opening port cannot be used because it is used for the exhaust plug.


■ Dimensions HP03E-16



■ Dimensions HP03E-16□ ※ J□










^{*1)} For the single acting type, the opening port cannot be used because it is used for the exhaust plug.

■ Dimensions HP03E-20











③

◈

View on Arrow A

■ Dimensions HP03E-20□※J□







View on Arrow A

^{*1)} For the single acting type, the opening port cannot be used because it is used for the exhaust plug.

■ Dimensions HP03E-25



■ Dimensions HP03E-25□※J□



^{*1)} For the single acting type, the opening port cannot be used because it is used for the exhaust plug.