
















## FLASHER RELAYS

New-Era No.	Ref.No.	Application
<b>FLS-101</b>  <b>AC24V</b>	<b>8-97360084-1</b> (066500-5651)	<b>INDICATOR RELAY (FLASHER RELAY)</b> ISUZU ELF NKR,NPR 
<b>FLS-102</b>  <b>AC24V</b>	<b>MC848790</b> (066500-2081) <b>MC849878</b> (066500-2080) (066500-2510) (066500-3040) (066500-3570) 819801650	<b>MITSUBISHI FUSO</b> HINO 
<b>FLS-103</b>  <b>AC24V</b>	<b>MB302374</b> (066500-1800)	<b>MITSUBISHI</b> CANTER 
<b>FLS-104</b>  <b>AC24V</b>	<b>1-83470062-0</b> <b>1-82550299-0</b> (066500-3860) (068300-0460)	<b>ISUZU</b> FORWARD EB03 
<b>FLS-105</b>  <b>AC24V</b>	<b>1-83470052-0</b> (066500-3251)	<b>ISUZU</b> ELF NKR,NKS,NPR,NPS 

## FLASHER RELAYS

New-Era No.	Ref.No.	Application
<b>FLS-106</b> <b>AC24V</b> 	<b>1-83470035-0</b> <b>(066500-0682)</b>	<b>INDICATOR RELAY (FLASHER RELAY)</b> <b>ISUZU</b> ELF NKR,NKS,NPR,NPS 
<b>FLS-109</b> <b>24V</b> 	<b>066500-1511</b> <b>066500-1512</b> <b>8-94143430-0</b> <b>8-19803701-1</b>	<b>ISUZU</b> ELF NKR NPR  <b>TOYOTA</b> DYNA BU MEGA CRUISER BXD20 TOYOACE BU 

## STOP LAMP SWITCHES

New-Era No.	Ref.No.	Application
<b>STP-001</b> <b>12V</b> 	<b>25320-H1000</b> <b>25320-H5001</b>  <b>For NISSAN</b>	