



# PICO UNIT Line Up



313 Page









# PICO UNIT Concept

PICO TABLE PPT10-20




PICO UNIT PPU10-45




Pico Unit PPU is a long stroke type of Pico Table PPT.

Pico Unit PPU is high accuracy and high rigidity since bearing of Pico Table PPT is installed.



### Stopper(Option) -


Size -



on Both Sides

With Shock Absorber With Rubber Stopper on Both Sides on Both Sides

Registration of a Design



## INDEX★

Overview314
Explanation, Example of Use, Installation Method $\cdots$ 315
Model Code No
Specifications, Guide to be used, Port Position $\cdots 317$
Spare Parts Code318, 319
Product Mass, Theoretical Thrust ·····320
Stroke Adjustment · · · · · 321
Structure and Principal Components322
Main Body and Load Bolt Mounting323
Accuracy324
Theoretical Deflection of Guide Table by Moment $\cdots 325$
Note for Safe Use326, 327
Allowable Load and Moment ······328~331
Dimensions332~359
Dimension of Stroke Adjuster ·····360~362
Switch Installation, Custom Made363

# **PICO UNIT**


PPU Series ( $\phi$ 10,  $\phi$ 12)

PPU series is an another version as PPT series for long stroke. The head table for attachment is united to the structure of PPT. (Miniature precision linear bearing with integrated air cylinder)

Running Parallelism 0.004 mm, Mounting Parallelism 0.02 mm



High Accuracy, High Rigidity Linear Guide is built-in.



Copper on body + electroless nickel plating

### Summary of the PICO UNIT (PPU) Series


The "PICO UNIT" (PPU series) is one of our family of miniature linear guide with integrated air cylinder, which can give high precision and high accuracy of linear guide itself to various application.

PPU series is derivative one from PPT.

PPU has longer stroke than PPT has and a useful front side for mounting. PPU also has abundantly many choices for use, which has three kinds of stroke adjustment, metal stopper, rubber stopper and shock absorber and installation of switch can detect position of stroke is available.

Refer to PPUH (with end lock).

### ■Application Examples: PICO UNIT





#### ■MAIN BODY INSTALLATION

(Bolt as shown in the figure are not supplied with products)

Top Mounting (Thru Hole used)

Bottom Mounting (Body Tap)







#### MOUNTING


(Bolt as shown in the figure are not supplied with products)

Front Mounting

Top Mounting







For details of stroke adjustment range Page 317

### **SPECIFICATIONS**

ooo					
Bore Size		φlOmm	φ12mm		
Rod Diameter		φ 4mm	φ 5mm		
	Without Stroke Adjustment	0.8kg	1.2kg		
Maximum	With Metal Stopper	0.3kg	0.5kg		
Load Mass	With Rubber Stopper	0.8kg	1.2kg		
	With Shock Absorber	1.6kg	2.0kg		
Port	Size	M5>	<b>(</b> 0.8		
Guide Mechanism		Precision Line	ar Ball Bearing		
Type of Operation		Double Acting			
Fluid		Air			
Maximum Operating Pressure		0.7 MPa			
Minimum Operating Pressure		0.15MPa			
With Shock Absorber		0.2 MPa			
Proof P	ressure	1.05MPa			
Operating Temperature		5~60°C			
Operating Speed		50~400mm/s			
Lubrication		Not required			
Cuphioning	Basic	Rubber Cushion (build in)			
Cushioning	Option	Rubber Stopper,	er, Shock Absorber		

<sup>\*</sup>PPU should be used within operating speed. Using out of operating speed may cause poor life or give damage to components.

### THE TYPE OF LINEAR BEARING

Model	Type
PPU10	IKO LWL12
PPU12	IKO LWL15

Pre-load:Zero or slightly pre-loaded

### STROKE ADJUSTMENT RANGE


Model Metal Stopper			Rubber	Stopper	Shock Absorber		
Model	QN	QR	QS	QT	QL	QM	
PPU10	Outstroke:15mm	Outstroke:15mm Instroke:5mm	Outstroke:15mm	Outstroke:15mm Instroke:5mm		Outstroke:19mm Instroke:16mm	
PPU12	Outstroke:15mm	Outstroke:15mm Instroke:5mm	Outstroke:15mm	Outstroke:15mm Instroke:5mm		Outstroke:18mm Instroke:16mm	

### PIPING PORT

The ports can be used properly according to the usage because ports are located on both sides of the body. However, note that the port position might be not changed according to the option.

The direction of the port should be determined by SD or GT, make sure the relation between the direction of the port and SD or GT on catalog.

Modification of port position Page 321



### Option which can be exchange the position of ports

_	Option which can be exchange the position of porte								
				Type of Option					
	Model	Without option (Basic)		Outstroke Side Rubber Stopper (QS)	Both Sides Rubber Stopper (QT)	Outstroke Side Metal Stopper (QN)		Outstroke Side Shock Absorber (QL)	Both Sides Shock Absorber (QM)
	PPU10	•	•	•	×	•	×	×	×
	PPU12	•	•	•	×	•	×	×	×

### **OPTIONAL PARTS CODES**


#### Name




#### Switch Fixture



#### Reed Switch(2 Wires, with Indicator Light) Straight Outlet Cable Angle Outlet Cable



#### Reed Switch(2 Wires, without Indicator Light) Straight Outlet Cable Angle Outlet Cable



### ●RB.RC Switch


Conventional RG1.RG2 switches

can be replaced to RB,RC switch


### Comparison with Old Type

Old type	Equivalent Current Type
RG1	RB1, RC1
	RB2, RC2
RG2	RB4, RC4
	RB5, RC5

#### Solid State Switch(2 Wires, with Indicator Light) Straight Outlet Cable Angle Outlet Cable



#### Solid State Switch(3 Wires, with Indicator Light) Straight Outlet Cable Angle Outlet Cable



#### Switch Rail



#### Magnet



mounting screws

#### Plug

BS-M5 with gasket	BR-M5 Coat BR-M5 with seal tapes or sealing liquid when using it.
<b>\$</b>	

### **OPTIONAL PARTS CODES**

#### Adjuster Bolt

,	
Object	PARTS CODE
PPU10 for outstroke	AJ(M5-30)
PPU10 for instroke	AJ(M5-22)
PPU12 for outstroke	AJ(M6-30)
PPU12 for instroke	AJ(M6-22)



with nut

#### Stroke Adjustment(Outstroke Side Rubber Stopper)

QS(PPU-AB-C)				
A :SD or GT, B:Bore size, C:Stroke				
Example: For PPU-GT10-15-TP,				
QS(PPU-GT10-15)				



#### Stroke Adjustment(Both Sides Rubber Stopper)

QT(PPU B-C)
B:Bore size, C:Stroke
Example: For PPU10 with 15 stroke, QT(PPU10-15)
400



#### Adjuster Bolt with Rubber

Aujustei Doit With Hubbei				
Object	PARTS CODE			
PPU10 for outstroke	AR(M5-30)			
PPU10 for instroke	AR(M5-22)			
PPU12 for outstroke	AR(M6-30)			
PPU12 for instroke	AR(M6-22)			



#### Stroke Adjustment(Outstroke Side Metal Stopper)

QN(PPU—A B—C)
A:SD or GT. B:Bore size.C:Stroke
Example: For PPU-GT10-15-TP,
QN(PPU-GT10-15)



#### r) Stroke Adjustment(Both Sides Metal Stopper)





#### Lock Nut for Adjustment Bolt

Object	PARTS CODE
M5(M5×0.8)	NTA(M5)
M6(M6×1)	NTA(M6)

Common use for Adjustment Bolt and Rubber Adjustment Bolt.

#### Stroke Adjustment(Outstroke Side Shock Absorber)

QL(PPU-AB-C)	Ξ
A:SD or GT. B:Bore size, D:Stroke Example: For PPU-GT10-15-TP, QL(PPU-GT10-15)	
-5	



#### Stroke Adjustment(Both Sides Shock Absorber)

QM(PPU	B-C)
B:Bore size, ©:Strok Example: For PPU10 v QM(PPU10-15)	
	with fixing bolts

### **∆** Caution

Before mounting, apply an anaerodic adhesive to the bolt.

#### Lock Nut for Shock Absorber

LOCK NUT TO CHOCK ADSOLDED					
Object	PARTS CODE				
ABK8(M8×0.75)	NTS(M8)				
0	î				

#### Shock Absorber



- Shock absorber is replaced to new type.
- It can be replaced to conventional shock absorber.

### MASS OF PPU

### ●MASS OF PPU

•										
	Bi-		Additional Mass	Additional Mass for Stroke Adjustment						
Model	Stroke	Basic Mass	for Magnet and Switch Rail	Outstroke Side Metal Stopper (QN)	Both Side Metal Stopper (QR)	Outstroke Side Rubber Stopper (QS)	Both Side Rubber Stopper (QT)	Outstroke Side Shock Absorber (QL)	Both Side Shock Absorber (QM)	
PPU10	15	230	15	35	55	35	55	45	75	
	30	270	20	45	65	45	65	55	85	
	45	320	25	55	75	55	75	65	95	
PPU12	20	320	17	45	80	45	80	55	95	
	30	370	20	55	90	55	90	65	105	
	45	425	25	70	105	70	105	75	115	
	60	495	30	85	120	85	120	90	130	

Note: The same mass for SD and GT.

### MASS OF SWITCH

MAGG OF GWITOFF	Unit: g
Switch Type	Mass
RB1, RB2, RB4, RB5	15
RC1, RC2, RC4, RC5	10
RB1LA, RB2LA, RB4LA, RB5LA	35
RC1LA, RC2LA, RC4LA, RC5LA	30

### METHOD TO CALCULATE THE MASS Ex. PPUS-GT10-45-TPQM-RB12LA

 Basic Mass·
 320g

 Magnet, Switch Rail·
 25g

 Shock Absorber
 95g

 Switch·
 35x2=70g

320+25+95+35×2=510g

### THEORETICAL THRUST

Unit: N


Unit: g

Bore Size	Operating	Operating Pressure MPa					
(mm)	Direction	0.2	0.3	0.4	0.5	0.6	0.7
φ10	Outstroke	16	24	31	39	47	55
	Instroke	13	20	26	33	40	46
φ12	Outstroke	23	34	45	57	68	79
	Instroke	19	28	37	47	56	65

1MPa=10.2kgf/ cm<sup>2</sup> 1N=0.102kgf

### ADJUSTMENT OF STROKE AND REPLACEMENT OF STOPPER -

### ■Metal Stopper And Rubber Stopper




#### Adjustment of Stroke

- 1. Loosen the fixing nut.
- 2. Turn the adjuster bolt until desired stroke is reached.
- Tighten lock nut keeping not to turn the adjuster bolt.

### Replacement of Stopper

- 1. Loosen the fixing nut.
- 2. Turn out the adjuster bolt from adjuster block.
- 3. Turn in the replacement adjuster bolt and adjust stroke.
- Tighten lock nut keeping not to turn the adjuster bolt.

### ■Shock Absorber



Refer to torque below to tighten the lock nut.

Lock Nut	Tightening Torque
M8×0.75	3.9N·m

### Adjustment of Stroke

- Loosen the fixing nut.
- 2. Turn the shock absorber until desired stroke is reached.
- 3. Tighten lock nut keeping not to turn the shock absorber


### Replacement of Shock Absorber

- Turn out the shock absorber from adjuster block, turn in the replacement shock absorber to the adjuster block.
- Turn the shock absorber until desired stroke is reached.
- Tighten lock nut keeping not to turn the adjuster bolt.

### ▲ Caution

- ①Abnormal noise of collision or vibration is recognized when the shock absorber or rubber stopper are used, it may mean the time to replace them because of their life. It will become the cause of breakage if it is then used.
- ②In case of the metal stoppers are used, rust may be generated on the contact surface during collision.
  Therefore periodic cleaning is recommended, not to give influence to accuracy of stop point position.

### MODIFICATION OF PORT POSITION



When PPU is delivered, the plugs (BS-M5) are attached to the ports.

A gasket is provided on the washer face of BS-M5.

Since BS-M5 can be easily mounted and removed with a wrench or a screw driver. You can freely change the position in accordance to your application such as symmetrical mounting.


If flat side surface is desired, the plug BR-M5 (hexagon socket set screw) is recommended.

In this case, it is necessary to apply seal tape or sealing agent on the thread portion.


#### NOTE

About QT, QR, QL, QM, it is NOT available to exchange the position of ports like the figure above. The position of the ports should be determined according to SD or GT in code. Option which can be exchange the position of ports. @page 317


### STRUCTURE AND PRINCIPAL COMPONENTS




Metal Stopper: Outstroke Adjustment




Metal Stopper: Both Sides Stroke Adjustment




Rubber Stopper: Outstroke Adjustment




Rubber Stopper: Both Sides Stroke Adjustment



Shock Absorber: Outstroke Adjustment



Shock Absorber: Both Sides Stroke Adjustment



PPU series can not be disassembled for repair.


No.	Name	Material	Remarks	No.	Name	Material	Remarks
1	Guide Table	Stainless Steel (Heat Treatment)		15	Circlip	Carbon Steel	Nickel Plating
2	Ball	Stainless Steel (Heat Treatment)	With Retainer	16	Washer	Carbon Steel	Nickel Plating
3	Body	Stainless Steel (Heat Treatment)		17	Nut	Carbon Steel	Nickel Plating
4	Dust Seal	NBR, Stainless Steel		18	Stopper Receiver	Tool Steel(Heat Treatment)	Electroless Nickel Plating
5	End Plate	Carbon Steel	Electroless Nickel Plating	19	Adjuster Block (for Outstroke)	Carbon Steel	Electroless Nickel Plating
6	Rod Cover	Aluminum Alloy		20	Adjuster Block (for Both Sides)	Carbon Steel	Electroless Nickel Plating
7	End Cover	Aluminum Alloy		21	Adjuster Bolt	Carbon Steel(Heat Treatment)	
8	Piston Rod	Stainless Steel		22	Adjuster Bolt (for Rubber)	Stainless Steel, Urethane Rubber	Nickel Plating
9	Plate Washer	Stainless Steel		23	Lock Nut	Carbon Steel	Electroless Nickel Plating
10	Piston Seal	NBR		24	Shock Absorber	Copper Alloy	Electroless Nickel Plating
11	Rod Seal	NBR		25	Lock Nut	Carbon Steel	Nickel Plating P10
12	0-ring	NBR		26	Bolt	Structural Alloy Steel	Nickel Plating
13	Cushioning Rubber	Urethane Rubber		27	Bolt	Structural Alloy Steel	Nickel Plating
14	Cushioning Rubber	Urethane Rubber		28	Metal Stopper	Carbon Steel	Heat Treatment (Nitriding)


PICO UNIT

### **BODY INSTALLATION ·**

### Top Mounting(Thru Hole used)

### Bottom Mounting(Body Tap)





Caution: Insert the two bolts by outstroke side from the side of body.

### **⚠** Caution

When mounting or removing the four bolts, tighten or loosen them carefully on average. If you tighten or loosen a specific bolt in the four bolts too mach, the linear guide will receive excess load and might be broken.


Model	Bolt Size	Thru hole length L(mm)	Fastening Torque N·m	Pin Holes for Positioning \$\phi D \times H (mm)
PPU10	МЗ	5	1.1	$\phi3^{+0.05}_{0}$ depth3
PPU12	M4	4.5	2.5	φ3 <sup>+0.05</sup> depth3


Model	Bolt Size	Screw depth L1(mm)	Screw depth L2(mm)	Fastening Torque N·m	Pin Holes for Positioning \$\phi D\times H(mm)\$
PPU10	M4×0.7	6.7	5	2.5	$\phi 3^{+0.05}_{0}$ depth 3
PPU12	M5×0.8	8.2	4.5	5.1	$\phi 3^{+0.05}_{0}$ depth 3

### MOUNTING ON TABLE

### Top Mounting

### Front Mounting







Model	Bolt Size	Screw depth L(mm)	Fastening Torque N·m	Pin Holes for Positioning \$\phi\text{D}\text{H}(mm)
PPU10	M3×0.5	3	1.1	φ3 <sup>+0.05</sup> depth2
PPU12	M3×0.5	4	1.1	$\phi$ 3 <sup>+0.05</sup> 0 depth2.5

Model	Bolt Size	Screw depth L(mm)	Fastening Torque N∙m
PPU10	M4×0.7	8	2.5
PPU12	M4×0.7	8	2.5

### ■Linear Bearing Accuracy






Unit: mm

Model		PPU10 PPU12		J12				
Stroke		15	30	45	20	30	45	60
Parallelism	Plane C with respect to plane A	0.02		0.02				
Parallelisiii	Plane D with respect to plane B	0.02		0.02				
Running	Plane C with respect to plane A	0.004		0.004		0.006		
Parallelism	Plane D with respect to plane B	0.004			0.004 0.00			0.006
Squareness	Plane E with respect to plane A	0.15		0.15				
	Plane E with respect to plane B	0.15		0.15				
Tolerance of Dimension F			±0.2 ±0.2		).2			
Tolerance of Dimension G		±0.2		±0.2				
Tolerance of Dimension H		±0.05		±0.05				
Tolerance of Dimension J			±0.025		±0.025			

### ■Parallelism of Adjustment Block (only SD)




In case of with stroke adjustment type, side plane of adjustment block can be used as datum plane for installation. "Parallelism 0.03mm"

### THEORETICAL DIFLECTION OF GUIDE TABLE BY MOMENT

Linear bearing used for PPU are preloaded, however, the elastic deformation of balls and races may occur due to the moment by external force.

Graphs below show the theoretical deflection angle of the guide table in relation to each moment.




4

6

Bending Moment N·m

8

10




### PRECAUTIONS FOR DESIGN AND USE

### 

#### Moment by Thrust of Cylinder at Offset Pushing

As the following figure, if cylinder will push work or so at the offset point in the middle of stroke, a large moment will be generated by the thrust of cylinder itself. Static moment rating page 331

### Pitching Moment



#### Mounting Surface Accuracy

- ①At the top, side of table and the bottom of body, the surfaces of PICO UNIT are ground up accurately. Stable and smooth movement highly accuracy can be obtained by proper installation to mounting surface machined high accurately. An irregular mounting surface or incorrect mounting may result in inaccurate movement, instability or poor service life. Datum plane (body and guide table) 🍑 page 324
- ②It is recommended to make relief at the corner of mating reference mounting surfaces. Besides, corner radius shown in the following figure can also be used.

If the corner profile is curved smoothly, compared to the chamfer profile of the body and guide table, it may not closely contact its reference surface.




③Check the reference mounting corner to an exact right angle between the mounting surface and the surface against which body or table is pressed. If the angle is not right-angled, they cannot contact the surface properly.





When designing a reference surface, carefully examine the height and thickness of the section. If a reference section is too thin, precision may deteriorate, as a thin ridge lacks rigidity against lateral load due to the movement of the body or guide table and the force exerted by the lateral mounting bolts.

#### Yawing Moment



#### Rigidity of Mounting Base (Fixed Part)

If the method of fixing the body and the rigidity of the mounting base are not correct, high rigidity and the high accuracy PICO UNIT has in kind could not be effective.

Consider it for design about also the rigidity of devices itself such as an attachment base.

#### Arranging Position of Shock Absorber

Pay attention to below about the position in the stroke end when mounted load mass will be larger than the one without shock absorber.

In order to stop the guide table, use stopper receiver and the metal on the top of shock absorber.

If the center pin in a table makes it stop in a body, by the mass of a loading thing is large, it causes breakdown

#### Lubrication

Lithium soap grease is applied on ball rolling surfaces before dispatch the unit. According to operation, time and condition for use, grease would be deteriorated and this cause the bearing to shorten its life because of wear on rolling surfaces.

Although the grease feeding interval depends on the service conditions and environment, as a rule, feeding should be performed every 100km of travel under normal usage or one month. Feed on raceway of the body as for lithium soap grease after wiping off old grease completely. The chemical change and poor performance by feeding the different grease would cause defective operation and the breakdown. Instead of grease, turbine oil can be used for lubrication. Never lubricate spindle oil machine oil because they give damage to the seals inside of the unit.



#### Feeling of Linear Guide Rolling

When the table is moved by hand without air pressure, discontinuous feeling of rolling balls on strange feeling of rolling resistance do not effect its performance.

#### Magnetization of Table and Body

Martensite stainless steel, as material of table and body, must be magnetized easily by contacting magnet and magnetic thing. Once that steel is magnetized, it keeps this state.

Note that there is a possibility that the switch might not work correctly by this magnetization.

#### Pin Hole of Table and Body for Positioning

Excessive load or transformation of raceway due to press-fitting the pin into the pin hole would cause the breakdown. Moreover, to press-fit would cause the crack and damage because of hardness of material by heat treated at the pin hole part.

Confirm the clearance between pin and pin hole.

### ALLOWABLE MOUNTED LOAD MASS, ALLOWABLE LOAD FORCE AND ALLOWABLE MOMENT -

### 


Before using this unit, check that the applied load is within the allowable load. Using out of allowable limit may cause bad influence for movement, accuracy and life. At the worst, the actuators would be broken.

Types of Load	Situation of Actuator	Situation of Load	Item to be confirmed
Mounted Load(W)	Operating	Continuously Acting	Allowable Mounted Load Mass, Allowable Mounted Load Moment, Allowable Inertia Mass, Allowable Absorber Collision Energy
External Force	Stopping	Temporarily Acting	Basic Static-load Rating, Allowable Static Moment


### ■Direction of Moment and Guide Center Line and/or Stopper or Stroke Adjuster

The moment directions are classified into three types in accordance with the mounting condition of a load to the actuator

### Without Stroke Adjustment



#### With Stroke Adjustment



#### Position of Guide Center

rusition of Guide Center on				
Model Stroke Guide Cente		Guide Center L		
	15	(X/2)+0.035		
PPU(H)10	30	(X/2)+0.043		
	45	(X/2)+0.050		
	20	(X/2)+0.039		
PPU(H)12	30	(X/2)+0.044		
FFU(N) 12	45	(X/2)+0.052		
	60	(X/2)+0.059		

#### Position of Stopper Bolt/Shock Absorber

I Init: m

Model	Adjust	er Bolt	Shock Absorber		
IVIOUEI	ℓp	ℓУ	ℓp	ℓУ	
PPU(H)10	0.0060	0.0180	0.0065	0.0200	
PPU(H)12	0.0060	0.0215	0.0065	0.0225	

W.....Mounted load mass(kg) F .....Gravity applied on load(N)

L ......Distance between front of guide table and guide center line(m) X ......Distance between front of guide table and front of body(m)

Lp,Ly,Lr.....Distance between guide center line and center of gravity of mounted load(m)

ℓ p. ℓ v ·····Distance between guide center line and stopper bolt/shock absorber(m)

S ......Distance between center of gravity of mounted load and stopper bolt /shock absorber(m)

### Allowable mounted load mass, Allowable mounted load moment, Allowable inertia mass, Shock absorber collision energy

When the actuator is operated with mounted load, confirm that the following four values are within the allowable range.

### ①Allowable Load Mass

Unit:kg

Model		PPU10	PPU12	PPUH10	PPUH12
	None	0.8	1.2	0.8	1.2
Allowable Load Mass	Metal Stopper (QN, QR)	0.3	0.5	0.3	0.5
	Rubber Stopper (QS, QT)	0.8	1.2	0.8	1.2
	Shock Absorber (QL, QM)	1.6	2.0		1.6

### ♠ Caution

When operating in the vertical direction, even if mounted load mass is within the allowable range, there might be some cases the thrust are not enough to move or to get the expected speed depending on supplied air pressure. Besides, there might be some cases the thrust are not enough to push the rod of the shock absorber to end. Theoretical thrust page 320

### ②Allowable Mounted load Moment

There is the formula below to calculate three moments by the gravity. Please confirm they are within the allowable moments in the table bellow.

((Mounted load moment)=(Gravity applied on load:F)×(Distance between guide center line and center of gravity of mounted load:L)
=9.8×(Mounted load mass:W)×(Distance between guide center line and center of gravity of mounted load:L)

(Gravity applied on load: F)=9.8×(Mounted load mass: W)

Pitching···Mp(N·m)=9.8×W(kg)×Lp(m) Yawning···My(N·m)=9.8×W(kg)×Ly(m) Rolling···Mr(N·m)=9.8×W(kg)×Lr(m)

### Allowable Mounted Load Moment

Unit :N·m

Model	Allowable Mounted Load Moment N·m			
Model	Мр	My	Mr	
PPU10/PPUH10	1.8	2.0	1.9	
PPU12/PPUH12	3.0	3.4	3.8	

1N·m=0.102kgf·m


### ③Allowable Inertia Mass


When a actuator stops at the end of its stroke, a force is generated due to the inertia of the load. The value of this force depends on various conditions like the shape of load, mounting ways and operating pressure. Therefore, it is very difficult to formulate the allowable value.

The graphs below show theoretically relation between "the velocity at the stroke end", "mounted load mass" and "the distance between the center of the gravity of load and stopper".

These graphs can be used as reference to the allowable values of the load.

S: The distance between the center of the gravity of load and stopper. Please refer to the figures of rolling in the previous page.






 $\triangle$  Caution: Mounted load mass should not exceed the allowable mounted load mass specified for every option.

### **4**Shock Absorber Collision Energy

The energy that the shock absorber of the stopper must absorb consists of three element: kinetic energy, energy of cylinder thrust and energy due to gravity.

The collision energy is the total of three.

See the shock absorber specifications and energy absorption graphs below. Use the product within the shock absorber specifications.



E: Collision energy(J)

m: Colliding mass(kg)

V: Collision velocity(m/s)

F: Cylinder thrust(N)


s : Shock absorber stroke(m)

g: Gravity acceleration(9.8m/S²)

#### SHOCK ABSORBER SPECIFICATIONS

ABK8		
0.68J		
5mm		
22.8J/min		
lm/s		
60c.p.m or less		
-5 ~ 70°C		
4.9N		

#### **Energy Absorption Graph**



#### Dimension of Shock Absorber

MODEL: ABK8


- Shock absorber is replaced to new type.
   It can be replaced to convertional shock absorber.
- 5(Stroke) M8×0.75

  M8×0.75

  M8×0.75

  M8×0.75

  M8×0.75



### ■ Allowable Load and Allowable Moment for External Force (Motionless)

In the case that an external force is applied temporarily when the actuator stops at the stroke end or so, confirm that the following two values are within allowable range.

- ①External Force Value (Basic Static Load Rating)
- ②External Moment (Static Moment Rating)

Note: The arm length of a moment shall be length from the guide center and the point where an external force is applied.

If a guide table receives an excessive load or a large impact, permanent deformation is locally generated between the ball and the ball rolling surface. This deformation will prevent the actuator from smooth operation when it develops more than the allowable limit. The basic static load rating Co, the static moment rating Mpo, Myo and Mro mean such a static load and static moment of constant direction and the total of the permanent deformation values at the ball rolling surface is 0.0001 times of the ball diameter on the contact surface receiving the maximum stress.

The static moment applied to the table is limited under CO, MpO, MyO and MrO with corsidering about static safty factor, fs.

Co≧fs·P

Mpo, Myo, Mro: Static moment rating N·m Mpi, Myi, Mri: Static moment N·m

fs: Static safety factor


#### STATIC SAFETY FACTOR fs


Load Conditions	Lower Limit of fs
Impact with Light Load	1.0~1.3
Impact with Heavy Load	2.0~3.0

#### BASIC STATIC LOAD RATING, STATIC MOMENT RATING

Model	Basic Static Load Rating	Static Moment Rating N·m			
Model	N	Mpo	Myo	Mro	
PPU10/PPUH10	3430	20.5	24.5	22.5	
PPU12/PPUH12	4900	32.3	38.2	41.1	

1N·m=0.102kgf·m 1N=0.102kgf





### With Metal Stopper, with Rubber Stopper

PPU(S)-SD10-15-TP-QN

-QS


−QR −QT


■QN: Outstroke Side Metal Stopper QS: Outstroke Side Rubber Stopper


Stroke Adjustment Range: 15mm


■QR: Both Sides Metal Stopper QT: Both Sides Rubber Stopper

Outstroke Adjustment Range: 15mm Instroke Adjustment Range: 5mm











With Shock Absorber PPU(S)-SD10-15-TP-QL


■QL: Outstroke Side
Stroke Adjustment Range: 15mm


### ■QM: Both Sides

Outstroke Adjustment Range:15mm Instroke Adjustment Range:15mm











-QM





### Without Magnet, Switch Rail

GT can be converted from SD by changing the port position of SD without magnet and switch rail. When magnet, switch rail and stroke adjustment is not necessary, select SD.

### With Metal Stopper, with Rubber Stopper

PPU(S)-GT10-15-TP-QN -QS


−QR −QT


■QN: Outstroke Side Metal Stopper QS: Outstroke Side Rubber Stopper


Stroke Adjustment Range: 15mm


■QR: Both Sides Metal Stopper QT: Both Sides Rubber Stopper

Outstroke Adjustment Range: 15mm Instroke Adjustment Range: 5mm










# With Shock Absorber PPU(S)-GT10-15-TP-QL -QM


■QL: Outstroke Side


Stroke Adjustment Range: 15mm


### ■QM: Both Sides


Outstroke Adjustment Range: 15mm Instroke Adjustment Range: 15mm











### With Metal Stopper, with Rubber Stopper


PPU(S)-SD10-30-TP-QN -QS -QR -QT


■QN: Outstroke Side Metal Stopper QS: Outstroke Side Rubber Stopper


Stroke Adjustment Range: 15mm

■QR: Both Sides Metal Stopper QT: Both Sides Rubber Stopper

Outstroke Adjustment Range: 15mm Instroke Adjustment Range: 5mm









# With Shock Absorber PPU(S)-SD10-30-TP-QL -QM


■QL: Outstroke Side
Stroke Adjustment Range: 19mm


### ■QM: Both Sides


Outstroke Adjustment Range: 19mm Instroke Adjustment Range: 16mm











### Without Magnet, Switch Rail

GT can be converted from SD by changing the port position of SD without magnet and switch rail. When magnet, switch rail and stroke adjustment is not necessary, select SD.

### With Metal Stopper, with Rubber Stopper

PPU(S)-GT10-30-TP-QN

-QS


−QR −QT

QN: Outstroke Side Metal StopperQS: Outstroke Side Rubber Stopper

Stroke Adjustment Range: 15mm

■QR: Both Sides Metal Stopper QT: Both Sides Rubber Stopper

Outstroke Adjustment Range:15mm Instroke Adjustment Range:5mm



## With Shock Absorber

PPU(S)-GT10-30-TP-QL -QM

■QL: Outstroke Side

Stroke Adjustment Range:19mm

16.5


42


### ■QM: Both Sides


16.5

70 **Max 1 1 4.7** 

Outstroke Adjustment Range:19mm Instroke Adjustment Range:16mm







### With Metal Stopper, with Rubber Stopper

PPU(S)-SD10-45-TP-QN

-08


-QR  $-\Omega T$ 


■QN: Outstroke Side Metal Stopper QS: Outstroke Side Rubber Stopper


Stroke Adjustment Range: 15mm

■QR: Both Sides Metal Stopper QT: Both Sides Rubber Stopper

Outstroke Adjustment Range: 15mm Instroke Adjustment Range: 5mm







15.5


With Shock Absorber PPU(S)-SD10-45-TP-QL -QM


■QL: Outstroke Side


Stroke Adjustment Range: 19mm


### ■QM: Both Sides


Outstroke Adjustment Range: 19mm Instroke Adjustment Range: 16mm











### Without Magnet, Switch Rail

GT can be converted from SD by changing the port position of SD without magnet and switch rail. When magnet, switch rail and stroke adjustment is not necessary, select SD.

### With Metal Stopper, with Rubber Stopper

PPU(S)-GT10-45-TP-QN

-QS

−QR −QT


 $-\Omega M$ 

■QN: Outstroke Side Metal Stopper QS: Outstroke Side Rubber Stopper

Stroke Adjustment Range: 15mm

■QR: Both Sides Metal Stopper QT: Both Sides Rubber Stopper

Outstroke Adjustment Range: 15mm Instroke Adjustment Range: 5mm





# With Shock Absorber PPU(S)-GT10-45-TP-QL

■QL: Outstroke Side
Stroke Adjustment Range: 19mm

### ■QM: Both Sides


Outstroke Adjustment Range:19mm Instroke Adjustment Range:16mm





### Without Magnet, Switch Rail PPU-SD12-20-TP





PPU(S)-SD12-20-TP-QN

-QS


−QR −QT


QN: Outstroke Side Metal StopperQS: Outstroke Side Rubber Stopper


Stroke Adjustment Range: 15mm


■QR: Both Sides Metal Stopper QT: Both Sides Rubber Stopper

Outstroke Adjustment Range: 15mm Instroke Adjustment Range: 5mm











With Shock Absorber PPU(S)-SD12-20-TP-QL -QM


■QL: Outstroke Side


Stroke Adjustment Range: 18mm


#### ■QM: Both Sides











PPU(S)-GT12-20-TP-QN -QS


–QS –QR –QT


QN: Outstroke Side Metal Stopper
QS: Outstroke Side Rubber Stopper

Stroke Adjustment Range: 15mm

■QR: Both Sides Metal Stopper QT: Both Sides Rubber Stopper


Outstroke Adjustment Range: 15mm Instroke Adjustment Range: 5mm







#### With Shock Absorber PPU(S)-GT12-20-TP-QL -QM


# ■QL: Outstroke Side Stroke Adjustment Range: 18mm







#### ■QM: Both Sides









PPU(S)-SD12-30-TP-QN

-QS


−QR −QT


■QN: Outstroke Side Metal Stopper QS: Outstroke Side Rubber Stopper


Stroke Adjustment Range: 15mm


■QR: Both Sides Metal Stopper QT: Both Sides Rubber Stopper

Outstroke Adjustment Range: 15mm Instroke Adjustment Range: 5mm











With Shock Absorber
PPU(S)-SD12-30-TP-QL
-QM


■QL: Outstroke Side


Stroke Adjustment Range: 18mm

#### ■QM: Both Sides









PPU(S)-GT12-30-TP-QN -QS


-QR -QT

QN: Outstroke Side Metal StopperQS: Outstroke Side Rubber Stopper

Stroke Adjustment Range: 15mm


■QR: Both Sides Metal Stopper QT: Both Sides Rubber Stopper


Outstroke Adjustment Range: 15mm Instroke Adjustment Range: 5mm



19

38







#### With Shock Absorber PPU(S)-GT12-30-TP-QL -QM


■QL: Outstroke Side


Stroke Adjustment Range: 18mm


#### ■QM: Both Sides











PPU(S)-SD12-45-TP-QN

-QS


−QR −QT


■QN: Outstroke Side Metal Stopper QS: Outstroke Side Rubber Stopper


Stroke Adjustment Range: 15mm

■QR: Both Sides Metal Stopper QT: Both Sides Rubber Stopper

Outstroke Adjustment Range: 15mm Instroke Adjustment Range: 5mm









With Shock Absorber PPU(S)-SD12-45-TP-QL -QM

■QL: Outstroke Side


Stroke Adjustment Range: 18mm

#### ■QM: Both Sides









PPU(S)-GT12-45-TP-QN

-QS


−QR −QT

QN: Outstroke Side Metal StopperQS: Outstroke Side Rubber Stopper

Stroke Adjustment Range: 15mm

■QR: Both Sides Metal Stopper QT: Both Sides Rubber Stopper

Outstroke Adjustment Range: 15mm Instroke Adjustment Range: 5mm




# With Shock Absorber

PPU(S)-GT12-45-TP-QL -QM

■QL: Outstroke Side

Stroke Adjustment Range: 18mm


#### ■QM: Both Sides



0.5±0.025

32±02

24 28



 $\phi 3^{+0.05}$  depth3

38

2-M5×0.8depth8.2

## With metal stopper, with rubber stopper

PPU(S)-SD12-60-TP-QN

**-08** 

-QR -QT


■QN: Outstroke Side Metal Stopper


QS: Outstroke Side Rubber Stopper


Stroke Adjustment Range: 15mm

■QR: Both Sides Metal Stopper QT: Both Sides Rubber Stopper

Outstroke Adjustment Range: 15mm Instroke Adjustment Range: 5mm










With Shock Absorber PPU(S)-SD12-60-TP-QL -QM


■QL: Outstroke Side Stroke Adjustment Range: 18mm

#### ■QM: Both Sides









PPU(S)-GT12-60-TP-QN

-08 -QR  $-\Omega T$ 


■QN: Outstroke Side Metal Stopper


QS: Outstroke Side Rubber Stopper


Stroke Adjustment Range: 15mm


■QR: Both Sides Metal Stopper QT: Both Sides Rubber Stopper

Outstroke Adjustment Range: 15mm Instroke Adjustment Range: 5mm













#### With Shock Absorber PPU(S)-GT12-60-TP-QL -QM

■QL: Outstroke Side Stroke Adjustment Range: 18mm ■QM: Both Sides











## DIMENSION OF STROKE ADJUSTER -

■Stopper Receiver (Mount on Table)




- ■Adjuster Block(Metal stopper) (Mount on body)
- ●For Outstroke Adjustment



Model	Stroke	Position	Parts Code	Α	В	С	D	Е	F	G	J	K
	15	SD	QN(PPU-SD10-15)	27								
	15	GT	QN(PPU-GT10-15)	~ /								
PPU10	30	SD	QN(PPU-SD10-30)	42	8	19	8	4	7	30	M5×0.8	2.5
		GT	QN(PPU-GT10-30)	42				4	′	30		2.5
	45	SD	QN(PPU-SD10-45)	57								
		GT	QN(PPU-GT10-45)	5/								
	20	SD	QN(PPU-SD12-20)	28								
		GT	QN(PPU-GT12-20)									
	00	SD	QN(PPU-SD12-30)	-00								
DDUI	30	GT	QN(PPU-GT12-30)	38	7.	0.1	10	_				
PPU12	45	SD	QN(PPU-SD12-45)		7.5	21	10	5	8	30	M6×1	3
	45	GT	QN(PPU-GT12-45)	53								
	00	SD	QN(PPU-SD12-60)									
	60	GT	QN(PPU-GT12-60)	68								

#### ●For Both Sides Stroke Adjustment




Model	Stroke	Parts Code	Α	В	С	D	E	F	G	Н	J	K
	15	QR(PPU10-15)										
PPU10	30	QR(PPU10-30)	69	8	19	8	4	7	30	22	M5×0.8	2.5
	45	QR(PPU10-45)	84									
	20	QR(PPU12-20)	58		7.5 21	10	5	8	30	22	M6×1	3
DDLLIO	30	QR(PPU12-30)	68	7.5								
PPU12	45	QR(PPU12-45)	83									3
	60	QR(PPU12-60)	98									
		(										

## ■Adjuster Block(Rubber Stopper) (Mount on Body)

#### ●For Outstroke Adjustment


SD GT



Model	Stroke	Position	Parts Code	Α	В	С	D	Е	F	G	J	K
	15	SD	QS(PPU-SD10-15)	27			8					
	15	GT	QS(PPU-GT10-15)	2/		19						
PPU10	30	SD	QS(PPU-SD10-30)	42	8			4	7	30	M5×0.8	2.5
_		GT	QS(PPU-GT10-30)	42				4	/	30		2.5
	45	SD	QS(PPU-SD10-45)	57								
	40	GT QS	QS(PPU-GT10-45)	37								
	20	SD	QS(PPU-SD12-20)	28	_						M6×1	
	20	GT	QS(PPU-GT12-20)									
	30	SD	QS(PPU-SD12-30)	38								
PPU12	30	GT	QS(PPU-GT12-30)	30	7.5	21	10	5	8	30		3
PPUIZ	45	SD	QS(PPU-SD12-45)	53	7.5	21	10	5	8	30	IVIOAI	٥
	45	GT	QS(PPU-GT12-45)	ಏತ								
	60	SD	QS(PPU-SD12-60)	68								
	60	GT	QS(PPU-GT12-60)	08								

## ●For Both Sides Stroke Adjustment


#### SD, GT




Model	Stroke	Parts Code	Α	В	С	D	Е	F	G	Н	J	K
PPU10	15	QT(PPU10-15)	54				4	7	30	22	M5×0.8	
	30	QT(PPU10-30)	69	8	19	8						2.5
	45	QT(PPU10-45)	84									
	20	QT(PPU12-20)	58				5	8	30	22	M6×1	
PPU12	30	QT(PPU12-30)	68	7.5	21	10						3
PPU12	45	QT(PPU12-45)	83	7.5	اعا	10						3
	60	QT(PPU12-60)	98									

- ■Adjuster Block(Shock Absorber) (Mount on Body)
- ●For Outstroke Adjustment


SD GT





Model	Stroke	Position	Parts Code	Α	В	С	D	Е	F	G	J
	15	SD	QL(PPU-SD10-15)	27							
		GT	QL(PPU-GT10-15)	2/						32	
PPU10	30	SD	QL(PPU-SD10-30)	42	4.2	19	12	2	11		M8×0.75
PPUIU	30	GT	QL(PPU-GT10-30)	42			12	2			IVIOAU.75
	45	SD	QL(PPU-SD10-45)	57							
		GT	QL(PPU-GT10-45)	37							
	20	SD	QL(PPU-SD12-20)	29							M8×0.75
		GT	QL(PPU-GT12-20)	29							
	30	SD	QL(PPU-SD12-30)	39							
PPU12	30	GT	QL(PPU-GT12-30)	39	4.7	21	12	2	11	32	
FFUIZ	45	SD	QL(PPU-SD12-45)	E1	4.7	21	12	_	' '	32	
	40	GT	QL(PPU-GT12-45)	54							
	60	SD	QL(PPU-SD12-60)	69							
		GT	QL(PPU-GT12-60)	69							


# ●For Both Sides Stroke Adjustment SD, GT



Model	Stroke	Parts Code		В	С	D	Е	F	G	J
	15	QM(PPU10-15)	55							M8×0.75
PPU10	30	QM(PPU10-30)	70	4.2	19	12	2	11	32	
	45	QM(PPU10-45)	85							
	20	QM(PPU12-20) QM(PPU12-30)				12	2	.,	00	M0v0 75
PPU12	30			4.7	21					
PP012	45	QM(PPU12-45)	85	4.7	21	12	2	' '	32	M8×0.75
	60	QM(PPU12-60)	100							

## INSTALLATION OF SWITCH -

## ■Switch Setting Position



#### RB(RC) 1. 2 Switch

Unit: mm

Model	Switch Sett	ing Position	On hold distance	Hysteresis			
iviodei	A B		( l )	(c)			
PPU10-15	1.3	16.3					
PPU10-30	1.3	31.3					
PPU10-45	1.3	46.3					
PPU12-20	1.4	21.4	6	1			
PPU12-30	1.4	31.4					
PPU12-45	1.4	46.4					
PPU12-60	1.4	61.4					

Note: In case of elbow tube fitting as a kind of speed controller is used, they may not turn their outlet position because of interference with the switch rail or stroke adjuster.

## BB(BC)4 5 Switch

Unit: mm

110(110)4, 0	Offic. IIIII						
Model	Switch Sett	ing Position	On hold distance	Hysteresis			
Wodei	Α	В	( \( \ell \)	(c)			
PPU10-15	3.3	18.3					
PPU10-30	3.3	33.3					
PPU10-45	3.3	48.3					
PPU12-20	3.4	23.4	2.5	1			
PPU12-30	3.4	33.4					
PPU12-45	3.4	48.4					
PPU12-60	3.4	63.4					


Explanation of hysteresis and on hold distance. Switch catalog

#### ■Installation of Switch

Assemble the fixing screw with a nut to the switch. Insert the switch into the groove.

After setting the position, fasten the screw by a screwdriver.

Fastening torgue of fixing screw must be 0.1 N·m.



#### Costom made ·

## To change grease

- Ochange the grease of bearing part to the other grease.
- There is a case might not be handled depends on kind of grease or request.
- Ocylinder part is lithium soap grease or fluorine grease.
- Grease of purchased item can not be exchanged.

Please ask us for more detailed infomation.









