


IVR-4xxx



IVR-401

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short


STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **14.0V~15.1V**■



IVR-402

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short


STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **14.0V~15.1V**■



IVR-403

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short


STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **14.0V~15.1V**■



IVR-404

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp
 STEP2 : Choke Drive ○
 Regulated voltage **14.0V~15.1V**■



LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**.....■

IVR-405

Connect IVR

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**.....■

IVR-406

Connect IVR

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**.....■

IVR-407

Connect IVR

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**.....■


IVR-408

Connect IVR

IVR-409

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short


STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **14.0V~15.1V**■



IVR-410

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **14.0V~15.1V**■




IVR-411

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **14.0V~15.1V**■


Connect "Cable Assy 2" between B and E terminal.



IVR-412


LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp
 STEP2 : Choke Drive ○
 Regulated voltage **14.0V~15.1V**■



This checker, CN-100, can not inspect IVR-413 due to its unique circuit design.

24V
○
12V
○




Connect IVR

IVR-413

LA S&Dummy Choke Drive T off R1 R2
 C off Choke Drive T off Off Off
 LB C on No Choke Drive T on Step1 Skip B-T Short

STEP1 : Charge Lamp
 STEP2 : Choke Drive ○
 Regulated voltage **14.0V~15.1V**■

24V
○
12V



Connect IVR


IVR-414

LA S&Dummy Choke Drive T off R1 R2
 C off Choke Drive T off Off Off
 LB C on No Choke Drive T on Step1 Skip B-T Short

STEP1 : Charge Lamp
 STEP2 : Choke Drive ○
 Regulated voltage **28.0V~29.1V**■

24V

12V
○



Connect IVR


IVR-415

LA S&Dummy Choke Drive T off R1 R2
 C off Choke Drive T off Off Off
 LB C on No Choke Drive T on Step1 Skip B-T Short

STEP1 : Charge Lamp
 STEP2 : Choke Drive ○
 Regulated voltage **28.0V~29.1V**■

24V

12V
○




Connect IVR

IVR-416

IVR-417

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **28.0V~29.1V**■




Connect IVR

IVR-418

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **28.0V~29.1V**■




Connect IVR

IVR-419

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short


STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **14.0V~15.1V**■



Connect IVR

IVR-420

This checker, CN-100, can not inspect IVR-420 due to its unique circuit design.



Connect IVR

LA	S&Dummy	Choke Drive	T off	R1	R2
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1: Charge Lamp

STEP2: Choke Drive

Regulated voltage **14.0V~15.1V**■

24V
○
12V
○

Connect IVR

IVR-421

LA	S&Dummy	Choke Drive	T off	R1	R2
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1: Charge Lamp

STEP2: Choke Drive

Regulated voltage **28.0V~29.1V**■

24V
○
12V
○

Connect IVR

IVR-422

This checker can not inspect IVR-423 due to its unique circuit design.

24V
○
12V
○

Connect IVR

IVR-423

This checker can not inspect IVR-424 due to its unique circuit design.

24V
○
12V
○


Connect IVR

IVR-424

IVR-425

This checker can not inspect IVR-425
due to its unique circuit design.

24V
○
12V
○




Connect IVR

IVR-426

This checker can not inspect IVR-426
due to its unique circuit design.

24V
○
12V
○




Connect IVR

IVR-427

This checker can not inspect IVR-427
due to its unique circuit design.

24V
○
12V
○



Connect IVR

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

24V
○
12V
○

STEP1 : Charge Lamp ○
STEP2 : Choke Drive ○
Regulated voltage■

Connect IVR