


IVR-5XXXX



IVR-5000

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short


STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **28.0V~29.1V**■



IVR-5001

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short


STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **14.0V~15.1V**■



IVR-5002

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short


STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **14.0V~15.1V**■



IVR-5003

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **14.0V~15.1V**■



LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**■

24V

12V

IVR-5004

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**■

24V

12V

IVR-5005

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**■

24V

12V

IVR-5006

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**■

24V


12V

IVR-5007

IVR-5008

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short


STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **14.0V~15.1V**■



IVR-5009

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short


STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **14.0V~15.1V**■



IVR-5010

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short


STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **14.0V~15.1V**■



IVR-5011

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **14.0V~15.1V**■



LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**.....■

24V

12V

Connect IVR

IVR-5012

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**.....■

24V

12V

Connect IVR

IVR-5013

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**.....■

24V

12V

Connect IVR

IVR-5014

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**.....■

24V

12V

Connect IVR

IVR-5015


IVR-5016

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **14.0V~15.1V**■

24V

 12V



Connect IVR


IVR-5017

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **14.0V~15.1V**■
 Only "CN-101" can inspect IVR-5017

24V

 12V



Connect IVR


IVR-5018

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **28.0V~29.1V**■

24V

 12V



Connect IVR


IVR-5019

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp
 STEP2 : Choke Drive
 Regulated voltage **14.0V~15.1V**■
 Only "CN-101" can inspect IVR-5019

24V

 12V



Connect IVR

LA 	S&Dummy C off	Choke Drive 	T off 	R1 Off	R2 Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**■

Only "CN-101" can inspect IVR-5020

Connect IVR

IVR-5020

LA 	S&Dummy C off	Choke Drive 	T off 	R1 Off	R2 Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**■

Only "CN-101" can inspect IVR-5021

Connect IVR

IVR-5021

LA 	S&Dummy C off	Choke Drive 	T off 	R1 Off	R2 Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**■

Only "CN-101" can inspect IVR-5022

Connect "Cable Assy2" between B and E terminal.

Connect IVR

IVR-5022

LA 	S&Dummy C off	Choke Drive 	T off 	R1 Off	R2 Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**■

Only "CN-101" can inspect IVR-5023

Connect IVR

IVR-5023

IVR-5024

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short


STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**■

Only "CN-101" can inspect IVR-5024

Connect "Cable Assy2" between B and E terminal.



IVR-5025


LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**■

Only "CN-101" can inspect IVR-5025



IVR-5026


LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**■

Only "CN-101" can inspect IVR-5026



IVR-5027


LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**■

Only "CN-101" can inspect IVR-5027



LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**■

Only "CN-101" can inspect IVR-5028

24V
○
12V

IVR-5028

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**■

Only "CN-101" can inspect IVR-5030

24V
○
12V

IVR-5030

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**■

Only "CN-101" can inspect IVR-5031

24V
○
12V

IVR-5031

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage■

24V
○
12V
○

Connect IVR