

IVR-8XXX





IVR-801

LA **S&Dummy** Choke Drive **T off** R1 R2
 C off  **No Choke Drive**  T on **Off**  Step1 Skip **Off**  B-T Short

STEP1 : Charge Lamp 
 STEP2 : Choke Drive 
 Regulated voltage **14.0V~15.1V**
 ※Connect Cable assy2. to IG and L terminals.
 Please refer to the Connection / Setting page

24V 
 12V 





Connect IVR

IVR-802

LA **S&Dummy** Choke Drive **T off** R1 R2
 C off  **No Choke Drive**  T on **Off**  Step1 Skip **Off**  B-T Short

STEP1 : Charge Lamp 
 STEP2 : Choke Drive 
 Regulated voltage **14.0V~15.1V**■

24V 
 12V 





Connect IVR

IVR-803

LA **S&Dummy** Choke Drive **T off** R1 R2
 C off  **No Choke Drive**  T on **Off**  Step1 Skip **Off**  B-T Short

STEP1 : Charge Lamp 
 STEP2 : Choke Drive 
 Regulated voltage **14.0V~15.1V**■

24V 
 12V 





Connect IVR

IVR-804

LA **S&Dummy** Choke Drive **T off** R1 R2
 C off  **No Choke Drive**  T on **Off**  Step1 Skip **Off**  B-T Short

STEP1 : Charge Lamp 
 STEP2 : Choke Drive 
 Regulated voltage **14.0V~15.1V**■

24V 
 12V 



Connect IVR

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**■

24V

12V

Connect IVR

IVR-806

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**■

24V

12V

Connect IVR

IVR-806

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**■

24V

12V

Connect IVR

IVR-807

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**

※Connect Cable assy2. to IG and L terminals.

Please refer to the Connection / Setting page.

24V

12V

Connect IVR

IVR-808

IVR-809

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short


STEP1 : Charge Lamp

STEP2 : Choke Drive ○

Regulated voltage **14.0V~15.1V**

※Connect Cable assy2. to IG and L terminals.

Please refer to the Connection / Setting page.



Connect IVR


IVR-840

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive ○

Regulated voltage **14.0V~15.1V**■



Connect IVR


IVR-841

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive ○

Regulated voltage **14.0V~15.1V**■



Connect IVR


IVR-842

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive ○

Regulated voltage **14.0V~15.1V**■



Connect IVR

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**■

Connect IVR

IVR-843

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**■

Connect IVR

IVR-844

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**■

Connect IVR

IVR-845

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**■


Connect IVR

IVR-846

IVR-847

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short


STEP1 : Charge Lamp
STEP2 : Choke Drive
Regulated voltage **14.0V~15.1V**■



IVR-848

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short


STEP1 : Charge Lamp
STEP2 : Choke Drive
Regulated voltage **14.0V~15.1V**■



IVR-849

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short


STEP1 : Charge Lamp
STEP2 : Choke Drive
Regulated voltage **14.0V~15.1V**■



IVR-850

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Skip No Check
STEP2 : Choke Drive
Regulated voltage **14.0V~15.1V**■



LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**■

Connect IVR

IVR-851

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**■

Connect IVR

IVR-853

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**■

Connect IVR

IVR-854

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive

Regulated voltage **14.0V~15.1V**■


Connect IVR

IVR-855

IVR-856

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short


STEP1 : Charge Lamp
 STEP2 : Choke Drive ○
 Regulated voltage **14.0V~15.1V**■



IVR-857

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short


STEP1 : Charge Lamp
 STEP2 : Choke Drive ○
 Regulated voltage **14.0V~15.1V**■



IVR-858

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short


STEP1 : Charge Lamp
 STEP2 : Choke Drive ○
 Regulated voltage **14.0V~15.1V**■



IVR-859

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp
 STEP2 : Choke Drive ○
 Regulated voltage **14.0V~15.1V**■



LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive ○

Regulated voltage **14.0V~15.1V**■

24V
○
12V

Connect IVR

IVR-860

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive ○

Regulated voltage **14.0V~15.1V**■

24V
○
12V

Connect IVR

IVR-861

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive ○

Regulated voltage **14.0V~15.1V**■

24V
○
12V

Connect IVR

IVR-863

LA	S&Dummy	Choke Drive	T off	R1	R2
	C off			Off	Off
LB	C on	No Choke Drive	T on	Step1 Skip	B-T Short

STEP1 : Charge Lamp

STEP2 : Choke Drive ○

Regulated voltage **28.0V~29.1V**■

24V

12V
○


Connect IVR

IVR-864

IVR-865

This checker, CN-101, can not inspect IVR-865 due to its unique circuit design.

24V
12V




Connect IVR

IVR-866

LA S&Dummy Choke Drive T off R1 R2
LB C off C on No Choke Drive T on Step1 Skip B-T Short

STEP1 : Charge Lamp 
STEP2 : Choke Drive 
Regulated voltage **28.0V~29.1V**■

24V
12V




Connect IVR

IVR-867

LA S&Dummy Choke Drive T off R1 R2
LB C off C on No Choke Drive T on Step1 Skip B-T Short

STEP1 : Charge Lamp 
STEP2 : Choke Drive 
Regulated voltage **28.0V~29.1V**■

24V
12V




Connect IVR

IVR-868

LA S&Dummy Choke Drive T off R1 R2
LB C off C on No Choke Drive T on Step1 Skip B-T Short

STEP1 : Charge Lamp 
STEP2 : Choke Drive 
Regulated voltage **14.0V~15.1V**■

24V
12V



Connect IVR